



Kids Obstacle

Attendants Recommended: 1 adult

General Rules To Follow During Use Of Unit:

1. All Persons MUST remove shoes before playing in Unit.
2. Children's safety depends on you. Only one player on the Obstacle at one time. Inflate The Fun Inflatables are top quality, well-engineered products, designed for the pleasure and safety of children. Use it Wisely!
3. To avoid Back injuries, flips are not allowed!
4. Absolutely no silly string, gum, candy, food, or other foreign substances are allowed on or in the obstacle.
5. One attendant should monitor the front of the obstacle, allow player to start, and once the payer reaches the middle of the obstacle allow another 1 player to start.
6. This ride was designed for any child 4 Years or Older.

Problems: Should your jump begin to deflate:

1. The motor (Blower) has stopped. Check cord to connection at outlet and on motor itself. Check circuit breakers. Remember, to use only One 50 ft extension cord per outlet. Stronger outlets are located in the Kitchen, Laundry rooms and garages.
2. Motor still running. Check air intake on side of the Blower for blockage, check both tubes connecting to the blowers on the unit, if they are lose retie if necessary.
3. In the event of Deflation, calmly evacuate the unit and identify the problem. If further assistance is needed please contact our office.

I the undersigned have read and agree to the safety requirements as show above.

Event Representative