



Endzone Obstacle

Attendants Recommended: 2 adult's One in Front/One in Back

General Rules To Follow During Use Of Unit:

1. All persons must remove shoes before playing in/on Unit.
2. Children's safety depends on you. Two individuals shall start at the front of the obstacle, after they have made their way to the slide, 2 more players may start. Inflate The Fun inflatables are top quality, well engineered products designed for the pleasure and safety of children, use it wisely.
3. To avoid back injury, flips are not allowed on any units!
4. Absolutely no silly string, gum, candy, food or other foreign substances in/on or around the inflatable.
5. One attendant shall monitor the front of the unit, two racers at one time. Once contestants reach the top of the slide allow another two racers to begin. Rear monitor reminds racers to slide feet first. No tumbling, flips or any other behavior that could cause bodily harm.
6. This ride was designed for anyone 5 years of age or older.

Problems: Should your jump begin to deflate:

1. Motor has stopped. Check cord to connection at outlet and on motor itself.
2. Check circuit breakers. Remember only one 50 ft cord and nothing else on that outlet. Stronger outlets are in the kitchen, laundry room and garage.
3. Motor still running, check air intake on side of the motor for blockage, check both tubes on back of the unit for snugness, retie if necessary.
4. If deflation occurs, calmly evacuate the unit and identify the problem.
5. Units must be returned in the same condition, as they were setup. It is the client's responsibility to clean, (if necessary) the unit before it is returned. If the unit is not properly cleaned we may charge a cleaning fee of no less then \$100.00 if the unit becomes damaged due to misuse on the clients behalf, the client shall be responsible for all repair cost..

I the undersigned have read and agree to the safety requirements as show above.

Event Representative