



Sports Cage

Attendants Recommended: 1 adult

General Rules To Follow During Use Of Unit:

1. All throwers get three balls to throw at the open holed catchers mitt.
2. Children's safety depends on you. Control over exuberance and showoffs. Inflate The Fun inflatables are top quality, well engineered products designed for the pleasure and safety of children and adults. Use it wisely.
3. ONLY ONE THROWER at a time!
4. Absolutely no silly string, gum candy, food, or other foreign substances are not allowed around the unit.
5. The sports cage comes with three balls (users must use balls provided, a charge of \$10.00 per ball will apply if balls are not returned).
6. The sports cage also comes with a radar device. You are also responsible for radar replacement due to intentional throws at unit.
7. The throwing distance may vary by the age group. Two throwing lines are recommended. One for younger individuals, one for older ages.
8. When retrieving the balls unzip the center ball return.
9. Do not sit on the arms of the inflatable.

Problems: Should your jump begin to deflate:

1. Motor has stopped. Check cord to connection at outlet and on motor itself. Check circuit breakers. Remember, only one 50-foot cord and nothing else on that outlet. Stronger outlets are in the kitchen, laundry room, and garage.
2. Motor still running. Check air intake on side of motor for blockage, check the tube on back of unit for snugness and retie if necessary.
3. In the event of excessive wind (20 miles per hour or greater) or rain, evacuate sports cage and deflate unit until poor weather has subsided.
4. A cleaning fee of no less than \$ 75.00 will be charged to client if unit is not returned in the same condition as in which it was dropped off. Client will be responsible for any damage incurred due to rough play or misuse of unit.

I the undersigned have read and agree to the safety requirements as show above.

Event Representative